SIDE SILL PANEL REMOVAL [PANEL REPLACEMENT]

id098008615300

Symbol Mark


SYMBOL MARK	MEANING
	SPOT WELDING
	ROUGH CUT LOCATION

ac5wzb00000071

Removal Procedure Side sill (front side)

1. Rough cut the 2 locations indicated by (A) shown in the figure.


Drill the 18 locations indicated by (B) shown in the figure.




3. Remove the cabin side outer frame (outer side sill).

Side sill (component)

- 1. Rough cut the 3 locations indicated by (A) shown in the figure.
- Drill the 114 locations indicated by (B) shown in the figure, then remove the cabin side outer frame (outer side sill).




Drill the 2 locations indicated by (C) shown in the figure, then remove the front fender set bracket.
Drill the 6 locations indicated by (D) shown in the figure, then remove the upper side sill reinforcement.




5. Drill the 1 location indicated by (E) shown in the figure.

ac5wzb00000272



6. Drill the 35 locations indicated by (F) shown in the figure.



7. Pull the side sill reinforcement from the inner side sill, hinge reinforcement and center pillar reinforcement, and then remove it.