REAR UPPER ARM REMOVAL/INSTALLATION [4WD]


id0214008008a2

Caution


Performing the following procedures without first removing the rear ABS wheel-speed sensor may
possibly cause an open circuit in the harness if it is pulled by mistake. Before performing the
following procedures, disconnect the rear ABS wheel-speed sensor (axle side) and fix it to an
appropriate place where the sensor will not be pulled by mistake while servicing the vehicle.

Note


- · Mark the position before removing the rear upper arm.
- Align the rear crossmember and rear upper arm markings when installing the rear upper arm.
- Tighten the rear upper arm inner bolt completely before installing the rear crossmember component to the vehicle.
- Disconnect the rear auto leveling sensor link. (With auto leveling sensor) (See AUTO LEVELING SENSOR REMOVAL/INSTALLATION.)



2. Disconnect the wiring harness clips and connectors installed to the rear crossmember.



3. Set the rear differential breather hose aside.




- 4. Disconnect the rear ABS wheel-speed sensor wiring harness installed to the hub support and set it aside. (See REAR ABS WHEEL-SPEED SENSOR REMOVAL/INSTALLATION.)
- 5. Remove the propeller shaft. (See PROPELLER SHAFT REMOVAL/INSTALLATION.)
- 6. Remove the TWC. (SKYACTIV-G 2.0, SKYACTIV-G 2.5) (See EXHAUST SYSTEM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
- 7. Remove the middle pipe. (SKYACTIV-D 2.2) (See EXHAUST SYSTEM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
- REAR ABS SENSOR

 N·m {kgf·cm, in·lbf}
 ac5uuw00000170

8-10 {82-101, 71-88}

- 8. Remove the rear coil spring. (See REAR COIL SPRING REMOVAL/INSTALLATION.)
- 9. Remove in the order indicated in the table.
- 10. Install in the reverse order of removal.
- 11. Inspect the wheel alignment and adjust it if necessary. (See REAR WHEEL ALIGNMENT.)




Rear upper arm
(See Rear Upper Arm Removal Note.)
(See Rear Upper Arm Installation Note.)

Rear upper arm bushing


(See Rear Upper Arm Bushing Removal Note.)
(See Rear Upper Arm Bushing Installation Note.)

Rear Upper Arm Removal Note


1. Jack up the vehicle to the unloaded condition, and support the rear trailing link component using a jack.



2. Align the rear crossmember component and rear upper arm and mark them.




3. Support the rear crossmember component with a jack and remove the rear crossmember installation nuts.



4. Press down on the rear crossmember component slowly until the rear upper arm inside installation bolts can be removed using a jack.

5. Remove the rear upper arm.





Rear Upper Arm Bushing Removal Note

- 1. Mark the rear upper arm as shown in the figure.
- 2. Press the rear upper arm bushing out using the **SSTs**.

Caution

 Set using the SST (49 U034 204) as shown in the figure to prevent damaging the rear upper and rear upper arm bushing and remove the rear upper arm bushing.







Rear Upper Arm Bushing Installation Note

1. Mark the new rear upper arm bushing as shown in the figure.

H¹: 6.0 mm {0.24 in}




2. Align the projection of a new rear upper arm bushing with the marks placed during removal.



3. Press fit the rear upper arm bushing until the marks placed in Step 1 cannot be seen using the SSTs.

Caution

 Set using the SST (49 U034 204) as shown in the figure to prevent damaging the rear upper arm and rear upper arm bushing and install the rear upper arm bushing.




Note


 Be careful when press-fitting the rear upper arm bushing because the bushing height of the inner and outer sides differs.

H²: 49.5 mm {1.95 in}

H³: 44.5 mm {1.75 in}




4. After installing the rear upper arm bushing, verify that it is installed to the position shown in the figure.




H⁴: 24.0±0.6 mm {0.945±0.02 in}


Rear Upper Arm Installation Note

- 1. Place alignment mark on the new rear upper arm in the same positions as the removed rear upper arm.
- 2. Install the rear upper arm.



Tightening torque 91—111 N·m {9.3—11 kgf·m, 68—81 ft·lbf}





ac5uuw00000188